

Quel SE5000 monter ?



SE5000 1B



Standard pour tous véhicules
ou remplacement référence d'origine
900208Rx.x/**XX***Rxx

5002 KRM (12/24V)

(**XX** = 02,04,05,16,18,20,24,25,32,34,36,38,41)

5011 KRM (24 V ADR)

(**XX** = 07,08,09,12,17,21,22,23,26,30,33,35,37)

SE5000 1C V2



Standard pour tous véhicules
ou remplacement référence d'origine
900588RX/ **XX***RXX
900773R/**XX***RXX

900773-35 KRM (12/24V)

(**XX** = 09,20,22,25,27,30,35,40)

900773-36 KRM (24 V ADR)

(**XX** = 10,21,26,28,31,36,41)

***XX**= numéro de variante constructeur